

HOW TO INSTALL

- 1) Put the motorcycle on a workstand so that the rear wheel is off the ground.




Make sure the vehicle is secured so it will not tip

- 2) Remove the seat and exhaust. Release the brake fluid reservoir.
- 3) Remove the lower attachments from the subframe and lift the subframe as far up that you can see the upper shock bolt.
- 4) Remove the upper and lower attachments of the original shock absorber, remove the collar band from the reservoir, loosen the PA bracket and remove the shock absorber.
- 5) Install the Tractive shock absorber and tighten the upper and lower attachments.



Make sure that all screws are tightened to the correct torque.

- 6) Mount the PA bracket like shown on the picture and mount the knob again.
- 7) Mount the reservoir like shown on the picture with the collar bands.
- 8) Reattach all parts. Make sure that all parts are installed in the same way as they were before the installation.




SET-UP DATA

Tractive recommendations:	Spring preload	:13	mm
	Rebound damping	:10	clicks
	Compression LS	:10	clicks (optional)
	Compression HS	:10	clicks (optional)



Read more about how to set up the vehicle and how to adjust the adjusters correctly in the Tractive Owner's manual.



Mounting Instructions

Model	: BMW F650GS DAKAR 00-
Part no.	: 46BM00-R3118 or : 46BM00-R3518 or : 46BM00-T6518

	Part no.	Pcs.
Contents box (without shock)	:90100001	1
	:Touratech sticker	2
	:Owner's manual	1
	:	
	:	



Before installing this product, check the contents of the kit listed above. If anything is missing, please contact your Tractive dealer.



Before installing this product, read the Tractive Owner's manual!