



## INSTRUCTION SHEET Yamaha FJR 1300 REAR 2006-2012

- Route the hose of the reservoir from the right side down. The Hose has to come out at the right side.
- Use the added hardware to mount the reservoir to the frame
- Mount the HPA adjuster knob also on the right side. See pictures. Use the added hardware to mount the adjuster knob to the frame.





**ADDED HARDWARE :**

Bolt M6x25	2 pcs
Bracket HPA	1 pc
Bracket reservoir to frame	2 pcs
Bracket reservoir	2 pcs