

Montagehinweis / Assembly advice

BMW F 800 S / ST

Typ: E8ST - Bj.: ≥ 2006

Federbein-Nr.: 640-/641-807-00

**Montageposition der Hydraulischen Federvorspannung /
Assembly position of the Hydraulic Preload Adjuster:**

