



BROWN MOTOR WORKS, INC. 885 W MISSION BLVD., POMONA, CA 91766

"EXCLUSIVE BMW MOTORCYCLE SALES & SERVICE" (909) 629-2132

INSTALLATION OF SIDE STAND

Remove nut for engine through bolt at rear of engine. (It is also the mount for the foot pegs.)

Back off the nut on the other side for the through bolt so that with side stand in place the amount of threads on each end of through bolt is equal.

Slide the clamp that holds the exhaust pipe at the foot peg mount forward. Then align with the forward hole in the side stand mount bracket.

Be sure the exhaust clamp is behind the side stand. Then insert the shouldered nut through the clamp and into the corresponding hole in the side stand.

Then install 8mm bolt with washer through the stand into the shouldered nut.

Tighten the larger (through bolt) first.

Make sure that equal threads are at each end.

Lastly, tighten furnished clamp bolt.

****WE DO NOT RECOMMEND ANY MODIFICATIONS TO THIS SIDESTAND.**

