

## BMW K1200RS HPA MOUNTING

Mount the Hydraulic Preload Adjuster Knob on the right side of the bike. Remove the passenger footrest, place the bracket between the footrest and sub frame. Put Blue Loctite on the original M8 bolts before mounting the footrest. Use the attached hardware to mount the knob on the bracket.

