



## INSTRUCTION SHEET BMW R 1100 R REAR 1994-2002

- Route the hose of the HPA the same way as original
- Use the added hardware to mount the adjuster knob on the added bracket.
- Use the original position to mount the knob



### ADDED HARDWARE :

Bolt M6x20  
Bracket HPA003

2 pcs  
1 pc